



Illustrated Parts List

Model Series

12H600

TYPE NUMBERS
0005 through 0342.

TABLE OF CONTENTS


Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	6
Flywheel	7
Flywheel Brake	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	7





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.


12H600










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5686-2 Assemblies include all parts shown in frames. 10/11/2004














914









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5686-3 Assemblies include all parts shown in frames. **10/11/2004**










Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5686-5 Assemblies include all parts shown in frames. **10/11/2004**


12H600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



1036 Emission Label



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5686-7 Assemblies include all parts shown in frames. 10/11/2004

12H600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	790363	Cylinder Assembly (Used After Code Date 04040400). Note _____ 699678 Cylinder Assembly (Used Before Code Date 04040500).	25	690021	Piston Assembly (Standard) Note _____ 692788 Piston Assembly (.010" Oversize) 692789 Piston Assembly (.020" Oversize) 692790 Piston Assembly (.030" Oversize)	51♦♦Δ	692799	Gasket-Intake
2	399269	Kit-Bushing/Seal (Magneto Side)				55	691421	Housing-Rewind Starter
3	★299819	Seal-Oil (Magneto Side)				58	697316	Rope-Starter (Cut To Required Length)
4	493279	Sump-Engine				60	281434	Grip-Starter Rope
4B	692509	Sump-Engine Used on Type No(s). 0005, 0110.	26	499631	Ring Set (Standard) Note _____ 692785 Ring Set (.010" Oversize) 692786 Ring Set (.020" Oversize) 692787 Ring Set (.030" Oversize)	65	690837	Screw (Rewind Starter)
5	695276	Head-Cylinder				78	691108	Screw (Flywheel Guard)
7	★Δ695166	Gasket-Cylinder Head				95	691636	Screw (Throttle Valve)
8	495786	Breather Assembly				97	499682	Shaft-Throttle (Metal) Note _____ 790121 Shaft-Throttle (Plastic)
9	★272481	Gasket-Breather				98	398185	Kit-Idle Speed
10	691125	Screw (Breather Assembly)	27	691866	Lock-Piston Pin	104	●691242	Pin-Float Hinge
11	499675	Tube-Breather	28	499423	Pin-Piston	108	691182	Valve-Choke
12	★692232	Gasket-Crankcase	29	499424	Rod-Connecting	109A	499779	Shaft-Choke
13	691137	Screw (Cylinder Head)	32	691664	Screw (Connecting Rod)	117	498981	Jet-Main (Standard) (Used After Code Date 03110600). Note _____ 498978 Jet-Main (Standard) (Used Before Code Date 03110700).
15	691680	Plug-Oil Drain (Square Socket)	32A	695759	Screw (Connecting Rod)	117A	694250	Jet-Main (Standard)
16	691456	Crankshaft Note _____ 691457 Crankshaft Used on Type No(s). 0111.	33	499642	Valve-Exhaust	118	497466	Jet-Main (High Altitude) (Used After Code Date 03110600). Note _____ 498975 Jet-Main (High Altitude) (Used Before Code Date 03110700).
17	692517	Bearing-Ball	34	499641	Valve-Intake			
20	★399781	Seal-Oil (PTO Side)	35	691304	Spring-Valve (Intake)			
22	691092	Screw (Crankcase Cover/Sump)	36	691304	Spring-Valve (Exhaust)			
23	696569	Flywheel Note _____ 697586 Flywheel Used on Type No(s). 0005, 0110.	37	694086	Guard-Flywheel			
24	222698	Key-Flywheel	40	692194	Retainer-Valve			
			43	691997	Slinger-Governor/Oil			
			43A	692505	Slinger-Governor/Oil Used on Type No(s). 0005, 0110.			
			45	690977	Tappet-Valve			
			46	694039	Camshaft			
			46B	694040	Camshaft Used on Type No(s). 0005, 0110.	118A	497466	Jet-Main (High Altitude)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
121	692703	Kit-Carburetor Overhaul	227	691467	Lever-Governor Control	334	691061	Screw (Magneto Armature)
122	692799	Spacer-Carburetor	238	691300	Cap-Valve	337	692051	Plug-Spark
125	694202	Carburetor	259	691189	Bracket-Casing Clamp	356	692390	Wire-Stop
125B	698056	Carburetor	265	690798	Clamp-Casing	358	694090	Gasket Set-Engine
127	694468	Plug-Welch	265A	691024	Clamp-Casing	363	19069	Puller-Flywheel
127A	691739	Plug-Welch	267	691044	Screw (Casing Clamp)	365	691136	Screw (Carburetor)
130	691203	Valve-Throttle	268	691025	Casing-Control Wire (Cut To Required Length)	383	19374	Wrench-Spark Plug
		Note	269	691026	Wire-Control (Cut To Required Length)	404	690272	Washer (Governor Crank)
		696564 Valve-Throttle (Used With Plastic Throttle Shaft)	270	691027	Nut (Control Wire Casing)	425A	690244	Screw (Air Cleaner Cover)
130A	691181	Valve-Throttle	271	691028	Lever-Control	443B	690255	Screw (Air Cleaner Primer Base)
133	398187	Float-Carburetor	276	271716	Washer-Sealing	445A	697029	Filter-Air Cleaner Cartridge
134	398188	Kit-Needle/Seat	287	690940	Screw (Dipstick Tube)	455	695161	Cup-Flywheel
137	693981	Gasket-Float Bowl	300	697590	Muffler-Exhaust	456	692299	Plate-Pawl Friction
146	690979	Key-Timing	300B	699769	Muffler-Exhaust	459	281505	Ratchet-Pawl
163	691894	Gasket-Air Cleaner	300C	694248	Muffler-Exhaust	505	694251	Nut (Governor Control Lever)
163A	692667	Gasket-Air Cleaner	304	695976	Housing-Blower	523	499621	Dipstick
187	691050	Line-Fuel (Cut to Required Length)			Note	524	692296	Seal-Dipstick Tube
188	691147	Screw (Control Bracket)			499677 Housing-Blower (Used on Type No(s). 0111.	525	495265	Tube-Dipstick
190	690940	Screw (Fuel Tank)			499676 Housing-Blower (Used on Type No(s). 0005, 0110.	529	692937	Grommet (Starter Motor)
192	694543	Adjuster-Rocker Arm	305	691108	Screw (Blower Housing)	562	691119	Bolt (Governor Control Lever)
202	691303	Link-Mechanical Governor			Note	584	697734	Cover-Breather Passage
209A	691851	Spring-Governor			691138 Screw (Blower Housing)	585	691879	Gasket-Breather Passage
		Note	306	691232	Shield-Cylinder	592	690800	Nut (Rewind Starter)
		693031 Flywheel (Used on Type No(s). 0005, 0110.	307	690345	Screw (Cylinder Shield) (Starter Motor)	597	691696	Screw (Pawl Friction Plate)
211	692434	Spring-Governed Idle	332	690662	Nut (Flywheel)	601	95162	Clamp-Hose
217	690354	Spring-Choke Return	333	802574	Armature-Magneto	608	497680	Starter-Rewind
222C	692617	Bracket-Control (Used on Type No(s). 0111, 0308.						
222E	697614	Bracket-Control (Used on Type No(s). 0334, 0342.						
222G	692615	Bracket-Control (Used on Type No(s). 0005, 0110.						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12H600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
613	691108	Screw (Muffler)	842	★691031	Seal-O Ring (Dipstick Tube)	972	693377	Tank-Fuel (Plastic)
613A	691140	Screw (Muffler)	843	691884	Sleeve-Lever	975	493640	Bowl-Float
615	690340	Retainer-Governor Shaft	847	692047	Dipstick/Tube Assembly	976	694395	Primer-Carburetor
616	698801	Crank-Governor	851	493880	Terminal-Sparkplug	977	692704	Gasket Set-Carburetor
619	691108	Screw (Cylinder Head Plate)	868	★Δ692044	Seal-Valve	988	692515	Gasket-Oil Adapter
621	692310	Switch-Stop	883	★Δ691893	Gasket-Exhaust	993	★Δ694088	Gasket-Cylinder Head Plate
633A●●691321		Seal-Choke/Throttle Shaft (Throttle Shaft)	886	696268	Gasket Set-Cylinder Head/Plate	1005	691346	Fan-Flywheel
635	66538	Boot-Spark Plug	914	691108	Screw (Rocker Arm Cover)	1022	★Δ691890	Gasket-Rocker Cover
676C	497682	Deflector-Muffler	921	692699	Cover-Blower Housing	1023	499624	Cover-Rocker Arm
677	690661	Screw (Muffler Deflector)	921A	699633	Cover-Blower Housing	1024	692508	Pump-Oil
670	692294	Spacer-Fuel Tank	922	692135	Spring-Brake	1026	692045	Rod-Push
684	690345	Screw (Breather Passage Cover)			Note ——— 691831 Spring-Brake Used on Type No(s). 0111.	1027	692513	Filter-Oil
689	691855	Spring-Friction	923	695891	Brake	1028	692516	Adapter_Oil Filter
718	690959	Pin-Locating			Note ——— 691994 Brake Used on Type No(s). 0111.	1029	691230	Arm-Rocker
737	692511	Screw (Oil Filter Adapter)	930	692691	Guard-Rewind	1034	691343	Guide-Push Rod
741	790345	Gear-Timing (Use Without Woodruff Key)	943	692514	Seal-O Ring (Oil Pump Cover)	1036	790635	Label-Emission (Used After Code Date 04063000).
		Note ——— 691830 Gear-Timing (Uses Woodruff Key)	957	692046	Cap-Fuel Tank (Plastic)			Note ——— 696767 Label- Emission (Used Before Code Date 04070100).
745	691648	Screw (Brake)	965	692507	Cover-Oil Pump	1055	692623	Tube-Oil Pump
750	691683	Screw (Oil Pump Cover)	966B	690243	Base-Air Cleaner Primer	1058	274979	Manual-Owner's
830	694544	Stud-Rocker Arm	967A	273356	Filter-Pre Cleaner	1059	692311	Kit-Screw/Washer
832	691466	Guard-Muffler	968A	691342	Cover-Air Cleaner	1095	694091	Gasket Set-Valve
836	691147	Screw (Muffler Guard)	968C	692692	Cover-Air Cleaner	1210	498144	Pulley/Spring Assembly (Pulley)
836A	697551	Screw (Muffler Guard)	969	691138	Screw (Blower Housing Cover)	1211	498144	Pulley/Spring Assembly (Spring)
						1330	272147	Manual-Repair

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.