



EXPLODED VIEW & PARTS LIST



EXPLODED VIEW & PARTS LIST

| NO. | PART NO. | DESCRIPTION | QTY. |
|-----|------------|---------------------------|------|
| 1 | PW3100-001 | Engine, CARB-Compliant | 1 |
| 2 | PW31-002 | Bolt M6x40 | 1 |
| 3 | PW31-003 | Detergent Tank Cap | 1 |
| 4 | PW31B-004 | Detergent Tank | 1 |
| 5 | PW31B-005 | Lower "A" Frame Assembly | 1 |
| 6 | PW31-006 | Lock Nut M8 | 1 |
| 7 | PW31-007 | Foot | 1 |
| 8 | PW31-008 | Phillips Head Screw M6x45 | 3 |
| 9 | PW31-009 | Lower Gun Hook | 1 |
| 10 | PW31-010 | Lock Nut M6 | 5 |
| 11 | PW31-011 | Lock Nut M8 | 8 |
| 12 | PW31-012 | Engine Mount | 4 |
| 13 | PW31-013 | Wheel Axle | 2 |
| 14 | PW31-014 | 12" Wheel | 2 |
| 15 | PW31-015 | Cotter Pin | 2 |
| 16 | PW31-016 | Tubing Clip | 2 |
| 17 | PW31-017 | Bolt M6x16 | 2 |
| 18 | PW31-018 | Spring | 2 |
| 19 | PW31B-020 | Bolt M6x55 | 2 |
| 20 | PW31-019 | Upper Gun Hook | 1 |
| 21 | PW3100-021 | Bushing | 2 |
| 22 | PW31-021 | Nozzle Holder | 4 |
| 23 | PW31-022 | Handle | 1 |
| 24 | PW31-023 | Foam Grip | 1 |
| 25 | PW31-024 | Bungee Cord Knob | 1 |
| 26 | PW31-025 | Bungee Cord | 1 |
| 27 | PW31-026 | Panel | 1 |
| 28 | PW3100-028 | Flat Washer M6 | 4 |
| 29 | PW31-028 | Siphon Tube | 1 |
| 30 | PW31-029 | Water Pump | 1 |
| 31 | PW31-030 | Flange Bolt M8x20 | 4 |
| 32 | PW31-031 | Output Shaft Key | 1 |
| 33 | PW31-032 | Lance | 1 |
| 34 | PW31-033 | Spray Gun | 1 |
| 35 | PW31-034 | Nozzle Cleaner | 1 |
| 36 | PW3100-036 | Nozzle Cleaner Sheath | 1 |
| 37 | PW28-005 | Drain Hose | 1 |
| 38 | PW31-036 | High Pressure Hose | 1 |
| 39 | PW31-037 | Red Nozzle, 0° | 1 |
| 40 | PW31-038 | Yellow Nozzle, 15° | 1 |
| 41 | PW31-039 | Green Nozzle, 25° | 1 |
| 42 | PW31-040 | White Nozzle, 40° | 1 |
| 43 | PW31-041 | Black Soap Nozzle | 1 |

EXPLODED VIEW & PARTS LIST



EXPLODED VIEW & PARTS LIST

| NO. | PART NO. | DESCRIPTION | QTY. |
|-----|----------|------------------------------------|------|
| 1 | PW31-101 | Crankcase | 1 |
| 2 | PW31-102 | Ball Bearing | 2 |
| 3 | PW31-103 | Oil Seal | 2 |
| 4 | PW31-104 | Governor Arm | 1 |
| 5 | PW31-105 | Governor Shaft | 1 |
| 6 | PW31-106 | Governor Shaft Washer | 1 |
| 7 | PW31-107 | Locking Pin | 1 |
| 8 | PW31-108 | Oil Drain Bolt | 2 |
| 9 | PW31-109 | Drain Bolt Washer | 2 |
| 10 | PW31-110 | Dowel Pin | 2 |
| 11 | PW31-111 | Piston | 1 |
| 12 | PW31-112 | Piston Ring Assembly | 1 |
| 13 | PW31-113 | Connecting Rod Assembly | 1 |
| 14 | PW31-114 | Piston Pin | 1 |
| 15 | PW31-115 | Piston Clip | 2 |
| 16 | PW31-116 | Crankcase Cover | 1 |
| 17 | PW31-117 | Oil Plug | 1 |
| 18 | PW31-118 | Dipstick | 1 |
| 19 | PW31-119 | Cylinder Head | 1 |
| 20 | PW31-120 | Intake Valve | 1 |
| 21 | PW31-121 | Exhaust Valve | 1 |
| 22 | PW31-122 | Intake Valve Return | 1 |
| 23 | PW31-123 | Valve Spring | 2 |
| 24 | PW31-124 | Intake Valve Seat | 1 |
| 25 | PW31-125 | Exhaust Valve Seat | 1 |
| 26 | PW31-126 | Push Rod Guide Plate | 1 |
| 27 | PW31-127 | Rocker Arm Bolt Assembly | 2 |
| 28 | PW31-128 | Rotator | 1 |
| 29 | PW31-129 | Stud Bolt | 2 |
| 30 | PW31-130 | Stud Bolt | 2 |
| 31 | PW31-131 | Carburetor Assembly | 1 |
| 32 | PW31-132 | Fuel Line | 1 |
| 33 | PW31-133 | Fuel Line Clip | 2 |
| 34 | PW31-134 | Governor Arm | 1 |
| 35 | PW31-135 | Governor Arm Bolt M6 | 1 |
| 36 | PW31-136 | Nut M6 | 3 |
| 37 | PW31-137 | Crankshaft Assembly | 1 |
| 38 | PW31-138 | Valve Lifter | 2 |
| 39 | PW31-139 | Crankcase Cover Gasket | 1 |
| 40 | PW31-140 | Camshaft Assembly | 1 |
| 41 | PW31-141 | Dowel Pin | 2 |
| 42 | PW31-142 | Bolt M8x30 | 6 |
| 43 | PW31-143 | Cylinder Head Gasket | 1 |
| 44 | PW31-144 | Bolt M8x60 | 4 |
| 45 | PW31-145 | Spark Plug, Torch F7TC (NGK BP7ES) | 1 |
| 46 | PW31-146 | Push Rod | 2 |

| NO. | PART NO. | DESCRIPTION | QTY. |
|------|------------|------------------------------|------|
| 47 | PW31-147 | Shroud | 1 |
| 48 | PW31-148 | Bolt M6x12 | 12 |
| 49 | PW31-149 | Cylinder Head Cover Gasket | 1 |
| 50 | PW31-150 | Cylinder Head Cover | 1 |
| 51 | PW31-151 | Recoil Bracket | 1 |
| 52 | PW31-152 | Bolt M6x20 | 1 |
| 53 | PW31-153 | Flywheel Assembly | 1 |
| 54 | PW31-154 | Recoil Fan | 1 |
| 55 | PW31-155 | Recoil Starter Pulley | 1 |
| 56 | PW31-156 | Nut | 1 |
| 57 | PW31-157 | Ignition Coil Assembly | 1 |
| 58 | PW31-158 | Bolt M6x25 | 2 |
| 59 | PW31-159 | Intake Gasket | 1 |
| 60 | PW31-160 | Carburetor Insulator | 1 |
| 61 | PW31-161 | Carburetor Insulator Gasket | 1 |
| 62 | PW31-162 | Carburetor Spacer | 1 |
| 63 | PW31-163 | Governor Rod | 1 |
| 64 | PW31-164 | Throttle Return Spring | 1 |
| 65 | PW31-165 | Recoil Starter Assembly | 1 |
| 66 | PW31-166 | Starter Switch | 1 |
| 67 | PW31-167 | Upper Shroud Assembly | 1 |
| 68 | PW31-168 | Air Filter Assembly | 1 |
| 68.1 | PW31-168-2 | Air Filter Element | 1 |
| 69 | PW31-169 | Governor Spring | 1 |
| 70 | PW31-170 | Clip | 1 |
| 71 | PW31-171 | Muffler Gasket | 1 |
| 72 | PW31-172 | Muffler | 1 |
| 73 | PW31-173 | Nut M8 | 2 |
| 74 | PW31-174 | Spring Washer M8 | 2 |
| 75 | PW31-175 | Fuel Tank Assembly | 1 |
| 75.1 | PW31-175-1 | Fuel Strainer | 1 |
| 76 | PW31-176 | Fuel Tank Cap | 1 |
| 77 | PW31-177 | Relief Valve Connecting Tube | 1 |
| 78 | PW31-179 | One Way Valve | 1 |
| 79 | PW31-187 | Breather Tube | 1 |
| 80 | PW31-180 | Fuel Line Clip | 1 |
| 81 | PW31-181 | Fuel Line Clip | 3 |
| 82 | PW31-182 | Bolt M6x28 | 1 |
| 83 | PW31-183 | Nut M6 | 2 |
| 84 | PW3100-184 | Wire Harness | 1 |
| 85 | PW31-185 | Rocker Arm Assembly | 2 |
| 86 | PW31-186 | Breather Tube Inlet | 1 |
| 87 | PW3100-187 | Carbon Tank Assembly | 1 |
| 88 | PW3100-188 | Carbon Tank Connecting Tube | 1 |
| 89 | PW3100-189 | Bolt M6x8 | 1 |